



LTL3000

Specifications

Optical specifications

Field of measurement:

- Width: 50 mm / 2 inch
- Height: 180 mm / 7.1 inch

Illumination angle R_L EN 1436: 1.24°

Illumination angle R_L ASTM E 1710: 88.76°

Observation angle R_L EN 1436: 2.29°

Observation angle R_L ASTM E 1710: 1.05°

Illumination angle Qd: Diffuse

Illumination angular spread:

- Horizontal: / Vertical: 0.33 / 0.17°

Observation angular spread: $\pm 0.17^\circ$

Equivalent observations distance: 30 m

R_L range (mcd·m-2·lx-1) 0 - 4000

Qd range (mcd·m-2·lx-1) 0 - 318

Instrument dimensions

Length: 420 mm / 16.5 inch

Width: 150 mm / 5.9 inch

Height: 300 mm / 11.8 inch

Weight: 4,7 Kg / 10.4 lbs

Construction:

Structural parts: Aluminum

Housing: Polymer

Keyboard: Silicone rubber & touch screen

Regulatory compliance

EU:

Radio: EN 303-413 V1.1.1:2017

EMC: EN 301-489-19 V2.1.1 (2019-04)

Safety: IEC 61010-1:2010, AMD1:2016; EN 61010-1:2010+A1:2019

USA:

FCC: 47 CFR Part 15B (class B)

Canada:

ICES-003:2016 (Class B)

Electrical characteristics

Power supply:

Battery: Rechargeable and replaceable Li-Ion 12V 3.0 Ah

Charging time: Approx. 1 hour 15 min.

External chargers:

- 230 V / 50 Hz
- 120 V / 60 Hz

Data

Data memory: 8 GB

Data transfer: USB 2.0

Typical repeatability: +/- 2%

Typical reproducibility: +/- 5%

Environmental specification

Temperature:

- Operating: 0°C to +60°C / 32°F to 140°F
- Storage: -10°C to +60°C / 14°F to 140°F
- Humidity: 20 - 85%, non-condensing
- Altitude: 4000 m / 13.000 feet

Timing

Measurement time: <1 sec.

Standards

EN 1436 (R_L & Qd), ASTM E1710 (R_L), ASTM E2177 (R_L wet), ASTM E2302 (Qd), ASTM E2367 (night colors)

General features

- Measurement time 1 sec
- Measures R_L on profiled markings up to 15 mm / 0.6 inch
- Memory 8GB
- Multi-lingual menu
- Easy-readable color touch LED display with 3 buttons
- Long-life LED light
- USB memory stick interface
- Power supply, standard Bosch professional battery
- Stray light compensated
- Single handed operation, user-friendly

Measurement features and data presentation

- R_L and Qd for dry & wet markings (R_L is standard delivery, Qd is optional)
- Nighttime chromaticity coordinates (x,y) (optional)
- Data presentation in Excel

Support features

- GNSS positioning (optional)
 - Latitude / Longitude format: Decimal degrees
 - Datum: WGS 84
- Shows and stores date and time
- Facility for entering and storing road ID and user ID

Standard delivery

- LTL3000 Retroreflectometer
- Hard-case transportation box
- R_L calibration standard with DANAK certificate
- Qd calibration / verification marking (if Qd is ordered)
- Battery charger
- Quick guide
- USB memory stick

Downloads

To be downloaded from www.roadsensors.com under 'Products':

- LTL3000 user manuals

Warranty

2 years

R&TTE Declaration of Conformity (DoC) and US Attestation of Conformity (AoC) can be supplied by DELTA upon request or viewed on: roadsensors.madebydelta.com/technical-background/certification

Specifications may be changed without notice.

